



- **Universal Replacement** – for Carlin, Beckett, Honeywell and ICM Controls
- **On-Board LCD Screen** – no special tool needed
- **Fully Programmable Settings**
- **32 Cycle Fault History**
- **Alarm Contacts**
- **Communications Port**
- **Serviceman Reset Protection**
- **Blocked Vent Protection**
- **Built-in Pump Prime**
- **Recessed Spade Connectors**
- **Provides CAD Cell Reading in OHMS**

It is important that the installation of the oil burner, piping and fittings, safety devices, controls, electrical wiring and equipment be done in accordance with national and/or local regulations of the authorities having jurisdiction over such installation.

Model 70200 Universal Oil Primary Control

Installation and Operating Instructions

For Use By Qualified Service Technicians Only

Power input (red/white wire)	120 VAC, 60 HZ, 9 VA
Limit circuit input (black wire)	120 VAC, 60 HZ
Motor load (orange wire)	10 FLA / 60 LRA (reduce by valve load)
Ignitor load (blue wire)	120 VAC, 60 HZ, 500 VA
Valve load (violet wire)	120 VAC, 60 HZ, 2A
Vent load	0.1 amp
Line heater	1 amp
Alarm contacts (dry contacts)	24V, AC/DC, 2A
Operating temperature limits	+32°F to +140°F
Storage temperature limits	-40°F to +185°F
Thermostat anticipator current	0.1 A, AC
Agencies	UL recognized (US & Canada)

Carlin Combustion Technology, Inc.

126 Bailey Rd
Ph 203-680-9401

North Haven, CT 06473
Fx 203-680-9403

WARNINGS

1. **Warning** – Do not attempt to confirm combustion simply by inspecting the flame visually. You must use combustion test instruments. Failure to properly verify/adjust combustion could allow unsafe operation of the burner, resulting in severe personal injury, death or substantial property damage. Refer to the burner manual for proper setup instructions.
2. **Warning** – Never test an ignitor by placing a screwdriver (or other metallic object) across the high voltage clips. Check ignitors only by observing spark at appliance ignition electrodes, with fuel supply OFF. Using any other method could cause ignitor damage and severe personal injury.
3. **Danger – Fire, explosion, or carbon monoxide hazard.** Water damage can lead to unreliable operation or cause the control to malfunction which could lead to severe personal injury or death. Do not install the control module where it can get wet. Always replace the control if it gets wet or if it has any signs of water residue.
4. **Warning – Electrical shock hazard.** To prevent electrical shock, death, or equipment damage, disconnect power supply before installing or servicing control. Only qualified personnel may install or service this control in accordance with local codes and ordinances. Read instructions completely before proceeding.
5. **Warning – Electrical shock hazard.** The ignition circuit of the control can produce over 10,000 volts which can cause severe injury or death.
6. **Warning – Frozen pipes/water damage.** Central heating systems are prone to shut down as a result of power or fuel outages, safety related fault conditions or equipment failure. Installation of freeze protection monitoring or other precautions are recommended for unattended dwellings in climates subject to sustain below—freezing temperatures.
7. **Warning** – All work must be performed by a qualified and licensed professional in accordance with all applicable codes and ordinances.
8. **Notice** – Read these instructions completely before proceeding with the installation.
9. **Notice** – Retain these instructions for future reference.
10. **Notice** – All wiring must comply with the National Electric Code or any other state or local codes or regulations.

Hazard Definitions

The following defined terms are used throughout this manual to bring attention to the presence of hazards of various risk levels or to important information concerning the life of the product.

DANGER

Indicates presence of hazards that will cause severe personal injury, death or substantial property damage.

WARNING

Indicates presence of hazards that will cause severe personal injury, death or substantial property damage.

CAUTION

Indicates presence of hazards that will cause minor personal injury or property damage.

NOTICE

Indicates special instructions on installation, operation or maintenance that are important but not related to personal injury or property damage.

Installing and Wiring

WARNING The 70200 control must be installed and serviced only by a qualified service technician.

Always disconnect power source before wiring to avoid electrical shock or damage to the control. All wiring must comply with applicable codes and ordinances.


Mounting

The control may be mounted on a 4" x 4" junction box in any convenient location on the burner, furnace or wall. The location must not exceed the ambient temperature limit, 140°F.

Wiring


Wiring must comply with local and national electrical codes, and with the following wiring diagrams.

6-Wire Recommended Wiring




3-Wire Replacement Wiring

NOTICE When connecting to BLACK power harness wire, without constant L1 power, wire nut together L1 (RED) and Limit In (BLACK) from control.




Low Voltage Wiring



WARNING Do not start the burner if the combustion chamber contains oil or oil vapor.

Initial Start-up/Power-up

When powered-up for the first time, the control will display a scrolling message “Does Burner Have A Solenoid Valve?”. Press **↑** for Yes or **↓** for No. This information is needed for proper operation of the control. **NOTE:** The control will not operate until this question is answered.



Does Burner...
Press **↓** =No **↑** =Yes

“Does Burner Have Solenoid Valve” will scroll on screen.

NOTE: This selection can be changed in the Settings Mode (see below for how to change settings)

View or Change Control Settings

NOTE: The settings mode cannot be accessed during a run cycle, the burner must be in standby mode (or lockout) to enter setup.

To enter the Settings Mode: Press the **↑** and **→** buttons simultaneously for 2 seconds. The display will show –

Settings Press **→**
To Exit Hold **←**

To View Current Settings: Press the **→** button to scroll through all Setting Modes (see table at the top of page 5 for Setting Mode options). The second line of the screen will display the current setting for each Setting Mode –

Valve Delay On
30 Seconds

Pressing the **→** button again will leave the setting as is and move to the next option –





Trial for Ign
15 Seconds

To Change a Setting: Scroll to the desired Setting Mode option using the **→** button (as described in table on page 5), then press the **↑** or **↓** button to scroll through the available Settings. When the desired setting is displayed on the screen press the **→** / **ENTER** button. The display will briefly indicate that the new setting has been “Entered” and the new setting will replace the previous setting on the second line of the screen. Continue pressing the **→** button to view the current setting for all options or **↓** button to make any desired changes.

Trial for Ign
30 Seconds

To Exit the Setup Menu: Press the **←** / **ESCAPE** button for 3 seconds. **NOTE:** The control will automatically exit the Setup menu after 30 seconds of inactivity or by a call for heat.

A V A I L A B L E S E T T I N G S

PRESS THE  BUTTON TO VIEW DIFFERENT SETTING MODES											
SETTING MODE OPTIONS 	Valve Delay On*	Trial for Ignition	Motor Delay Off*	Flame Stabilize	CAD Ohms Max	Ignition Type	TT Jumped**	Vent Input	Allowed Recycles	Clear Fault History	Restore Factory Defaults
PRESS THE   BUTTONS TO CHANGE SETTINGS	No Valve	15 Sec	0 Sec	Off	Carlin 3300	Interrupted	Yes	Not Used	None	Yes	Yes
	0 Sec†	30 Sec	10 Sec	5 Sec	Other 5300	Smart Ign	No	Intake	3	No	No
	3 Sec†	45 Sec	15 Sec	10 Sec							
	10 Sec		30 Sec	15 Sec							
	15 Sec		2 min	30 Sec							
	30 Sec		5 min	45 Sec							
	60 Sec		15 min								
	2 min										

Shaded box = default setting; CAD Ohms Max default is application dependent.

*When selecting “No” valve during initial startup, “Valve Delay On” will be set to “No Valve” and “Motor Delay Off” will be set to “0 Sec”.

**Changing this setting to ‘Yes’, with limits powered will exit Settings mode and result in immediate ‘Call For Heat’.

†If flame is sensed during valve delay on, control will lockout immediately (except when Valve Delay On is set to 0 or 3 seconds).

Setup Menu Definitions

- **Valve Delay On:** Time period motor and ignitor are on prior to Trial for Ignition. This setting is often referred to as “pre-purge”. **Note:** If flame is sensed during valve delay on, control will lockout immediately (except when Valve Delay On is set to 0 or 3 seconds).
- **Trial for Ignition:** Flame-establishing period during ignition.
45 sec TFI up to 3 GPH
15 sec TFI up to 19.9 GPH
- **Motor Delay Off:** Time period the motor is on after the Call for Heat is satisfied to allow for evacuation of combustion gases. This setting is often referred to as “post-purge”. A call for heat during Motor Delay Off will result in a recycle. **Note:** If Valve Delay On is set to “0 Seconds” or “No Valve”, Motor Delay Off can only be set to “0 Seconds”.
- **Flame Stabilize:** The time period after Trial for Ignition that the ignitor remains on to stabilize flame.
- **CAD Ohms Max:** The maximum Ohms range that the control will allow the burner to operate.
- **Ignition Type**
Interrupted: Spark is turned off after Flame Stabilization period.
Smart Ignition: If flame is lost at any time after the Flame Stabilization period, the control will recycle (60 - 65 seconds). Following this recycle, the control will operate in Intermittent Duty mode (ignition on throughout the call for heat) for ten heat cycles. Following these ten cycles, the control will revert back to Interrupted Duty and will remain in Interrupted Duty until another recycle event occurs.
- **TT Jumped:** Allows TT to be “jumped” by software program.
- **Vent Input:** Applicable only to applications equipped with a combustion air proving switch (Intake) or a blocked vent switch (Exhaust): The Intake setting has a 10 second delay before shutting down in the event the air intake is blocked. The burner will recycle (subject to the Allowed Recycles setting). The Exhaust setting allows for a 30 second delay after flame is proven at each burner start up. If the vent is blocked at the conclusion of the 30 second delay, the burner will shut down and lock-out immediately. If the vent is not blocked at start-up, but becomes blocked sometime after the 30 delay, the burner will shut down immediately, but will be allowed to recycle (subject to the Allowed Recycles setting). Note: The above assumes the blocked vent switch is not equipped with its own manual reset feature.
- **Allowed Recycles:** Number of Recycles allowed during a single Call for Heat prior to lockout.
- **Clear Fault History:** Allows all prior burner fault conditions stored in control to be cleared.
- **Restore Factory Defaults:** Allows all factory defaults to be restored in control (refer to settings shaded in gray in the table above). Will reset and reboot control and require answer to “solenoid valve” question at startup.

NOTICE

Per UL requirements, the control will not turn on if the cad cell senses flame (light) during the self-test. If the cad cell sees flame, the control will remain in self-test mode until the cad cell no longer senses flame.

Operating Sequence

With power to the control and all manual oil line valves open, set thermostat (and limit) to call for heat. **NOTE:** The thermostat circuit must be closed and power must be coming to black wire from limit circuit.

Pre-Ignition
XX Sec

Following a 3 sec **Pre-Ignition**, the control advances to Valve Delay On –

Valve Delay On
XX Sec

During **Valve Delay On**, motor starts. After set timing, valve opens and the control advances to Trial for Ignition when the countdown clock expires. **NOTE:** For the Valve Delay to operate, the burner must be equipped with a solenoid valve that is wired to the violet terminal.

Trial for Ign
XX Sec

During **Trial for Ignition**, the CAD cell must sense flame or the control will go into lockout. When flame is detected, the screen will briefly display “Flame Detected” and then return to the “Trial for Ign”. When the countdown timer expires, the control advances to Flame Stabilization

NOTE: Push View Ohms button anytime during burner operation to view the CAD Ohms reading.

Flame Stabilize
XX Sec

When the **Flame Stabilize** timer expires, the ignitor will turn off and the burner will continue to fire until the Call for Heat ends or the limit string opens. The screen will display “Burner Running”. **Note:** If Smart Ignition is selected in the Setup Menu, the screen will alternate between “Burner Running” and “Smart Ign Active” at any time the ignitor is running in intermittent mode.

Burner Running
59 Sec

When the Call for Heat ends (or a limit control interrupts the burner circuit), the oil valve (if installed) will turn off within 2 seconds. The motor remains on for the Motor Delay Off period. When the Motor Delay Off timer expires, the control returns to Standby mode awaiting the next call for heat.

Motor Delay Off
XX Sec

Standby 59 Sec
No Call for Heat

Pump Prime (Bleeding)

The 70200 control is equipped with a 120 second pump prime feature. To enter Pump Prime, there must be a Call for Heat. **NOTE:** If a flame is present, the control will not enter Pump Prime mode.

To bleed the oil line, with Limit icon on, push and hold red **Reset** button for 10 seconds. The display will read **Pump Prime**.

The motor, valve and ignitor remain on for up to 2 minutes while in Pump Prime mode. To end Pump Prime mode, press the red **Reset** button. **NOTE:** If flame is sensed, Pump Prime mode ends in 5 sec.



Pump prime cannot be entered when the control is in Lockout or Latch-up.

Status Icons



Status Icons will appear at the top of the 70200 display to indicate the control's current operating condition.

POWER	Indicates that the control is powered (flashes if voltage is too low or too high)
TT	Displayed when the TT terminals are physically jumpered, jumpered in the set-up menu, or when thermostat is calling for heat.
LIMIT	Indicates that the burner limit circuit is powered.
IGNITOR	Indicates that the ignitor is energized (flashes if ignitor not detected)
MOTOR	Indicates that the motor is energized (flashes if motor not detected)
VALVE	Indicates that the valve is energized (on entry to pump prime will flash if not detected)
BV	Indicates vent input is active (when vent input is selected)
FAULT	Flashes in unison with other status icons indicating a problem exists in that area
FLAME	Indicates the CAD cell is sensing flame


Fault History

The 70200 stores information from the last 32 cycles in which a fault condition occurred. To Enter the Fault History , simultaneously press and hold the  and  buttons for 2 seconds. The display below will appear –


View 13 Faults 
To Exit Hold 

Press the  button to scroll through the history of fault conditions. Fault 1 is the most recent cycle in which a fault occurred. To view faults experienced in earlier run cycles, continue to press the  button. The control will display Fault 2 followed by Fault 3, etc.


Fault 1 Details 
View Fault 2 

To view the details of any fault (ex. Fault 1 in the screen above), press the  button to see the Fault Message.


Fault 1 Message
No Flame Check Vlv

Press the  button again to determine how many cycles ago the fault occurred.


Fault 1
XXXX cycles ago

Press the  button again to determine if the fault resulted in a lockout or a recycle.



Fault 1 Result
Lockout


Press the  button again to examine the Ohms at the time of the fault.

Fault 1
CAD XXXXX Ohms



Continue pressing the  button to examine the following information recorded during the fault cycle.

- Line Voltage
- Motor Amps (OK or Low)
- Ignitor Amps (OK or Low)
- Valve Amps (OK or Low)
- Recycle (Yes or No)
- Burn Time
- Flame Delay


On any fault detail screen listed above, the  button can be pressed to view the same data in the previous fault cycle. For example, if in Fault 1 (the most recent fault), the Ignitor Amps were low, by pressing the  button, the Ignitor Amps in Fault 2 (the previous fault cycle) will be displayed.

To Exit Fault History: Press and hold the  / **ESCAPE** button for 3 seconds at any time.

Total/Run History

In addition to the Fault History (left), the 70200 also logs the total run history of the control. To enter this menu, simultaneously press the  and  buttons for 3 seconds. The display below will appear.

Total History 
To Exit Hold 


To Exit Total History: Press and hold the  / **ESCAPE** button for 3 seconds at any time.

Press  button to scroll through the history which includes:

- Total On Time
- Total Burn Time
- Total Burner Run Cycles
- Faults Cleared (cycles ago)
- Max Line Volts
- Min Line Volts
- Total Recycles

FAULT HISTORY

NOTE: Fault information in chart is representation only.

PRESS THE  BUTTON TO VIEW NEXT FAULT						
		FAULT 1	FAULT 2	FAULT 3	FAULT 4	FAULT 5
Message		No Flame ck vlv	No Flame ck vlv	No Flame ck vlv	No Flame ck vlv	No Flame ck vlv
Cycles Ago		2	3	4	5	6
Result		Lockout	Lockout	Lockout	Lockout	Lockout
CAD Ohms		999999	3300	2500	1500	1500
Line Volts		114	114	114	114	114
Motor Amps		OK	Low	OK	OK	OK
Ignitor Amps		OK	OK	Low	OK	OK
Valve Amps		Low	OK	OK	Low	Low
Recycle Y/N		No	No	No	No	No
Burn Time		16 sec	16 sec	16 sec	16 sec	16 sec
Flame Delay		15 sec	15 sec	15 sec	15 sec	15 sec

PRESS THE
 
BUTTONS
TO
VIEW
FAULT
DETAILS



Service and Troubleshooting

Last Fault Display: When the control is reset from a lockout condition, if the burner resumes normal operation, the screen will toggle the last fault and its cause for five days (longer duration if control is not wired for constant power). This feature is designed to allow the service technician to easily see what caused the condition in the event the homeowner reset the control prior to his arrival. The screen will alternate between displaying what the last fault was and displaying how to clear the message **hold ESC for 3 seconds**.

Last Fault
No Flame Chk Ign

Toggle

To Clear Message
Hold  3 Sec

Display Voltage and Current: Press  +  for 3 seconds to display real time voltage and current.

Amps = 7 mA
Line = 115 VAC


Lockout: If lockout occurs, the screen turns on, the fault icon flashes and a fault message is displayed on the screen. **To Reset** Push in and hold the red **Reset** button for 1 second, then release. **NOTE:** Recycling power to the control will not reset it from it from a lockout condition.

Two fault conditions result in an immediate lockout. These include; Flame detected during pre-purge and flame failure during Trial for Ignition. All other faults will result in a Recycle (unless the Allowed Recycles is set to 'None' in the Set-up Menu). A **Recycle** results in the burner shutting down for 60 seconds then resuming operation in Standby (if there is no Call for Heat) or initiating the Operating Sequence above (if there is a Call for Heat).

Latch-up: If the control locks out 3 times during a single Call for Heat, Latch-Up will be displayed on screen.

To Reset the control after latch-up, press and hold the red Reset button for 30 seconds. **WARNING: Only a qualified service technician should attempt to reset the control after latch-up. The problem that caused the repeat lock-outs must be corrected before returning the burner to normal operation.** **NOTE:** Recycling power to the control will not reset it from it from a latch-up condition.

Burner will not fire

- Check line voltage to the control (at least 102 vac).
- Check all electrical connections.
- Is CAD cell seeing light?
- Light is leaking into the burner housing
- CAD cell is defective
- There is a problem with the CAD cell wiring or holder
- If appliance was recently shut down, CAD cell may see residual hot spots in chamber. To troubleshoot, press the  button to display cad cell Ohms. Dark resistance should be over 50,000 ohms and room light resistance (control flipped open) should be less than 10,000 ohms. Replace cell if necessary, or reinstall and close the burner housing. Check for stray light by measuring the CAD cell resistance looking into the inactive combustion chamber. It should read greater than 50,000 ohms.

Other no start problems:

- Valve lead voltage on too early. Correct bad connection.
- Motor relay welded. If valve has no voltage, and line voltage is okay (102 - 132 VAC), the issue is a welded motor relay. Replace the control.
- Motor current less than 0.2 Amps.

Blocked vent – not recycling:

- Recycle only works on non-manual reset vent switch

Repeated flame failures

- CAD cell is defective. Replace.
- Air leaking into oil line causing flame out – check oil line connections and filter gasket.
- Defective nozzle causing flame to be erratic – change nozzle.
- Excessive airflow or draft causing flame to leave burner head. Check for proper air band setting and draft.
- Excessive back pressure causing flame to be erratic – check appliance and flue for sooting/plugging.

Control locks out at end of TFI

- No oil to burner – check oil supply, filters, lines.
- Shorted electrodes – inspect for cracked porcelain and replace as needed.
- Poor spark – check electrode spacing and condition per burner manual. Replace or realign if necessary.
- Nozzle clogged – replace nozzle.
- Airflow too high – check air band setting.
- Ignitor module defective – replace if no spark.
- CAD cell defective.
- Oil valve (if used) stuck in closed position.
- Check wiring connections.

FROZEN PIPES/WATER DAMAGE

This is not a freeze protection device. Suitable freeze protection monitoring or other precautions are recommended to protect against ruptured pipes/water damage caused by fuel outage, safety related fault conditions or equipment failure.

TECH SUPPORT HOTLINE 800-989-2275

Carlin[®]
Combustion Technology, Inc.

Carlin Combustion Technology, Inc.

126 Bailey Road North Haven, CT 06473 Phone 203-680-9401 Fax 203-764-1714
e-mail us at: info@carlincombustion.com visit our website: www.carlincombustion.com