

PARTS LIST - P250AF SERIES GAS BURNERS

Part No.	Description	No. Req'd	P250AF	P250AF EP	P250AF DI
62903-001	Control Box/Strap Assembly	1	•	•	•
60182-002	Power Cord Assembly	1	•		
60186-004	Transformer-24V	1	•	•	•
100986-002	Relay	1	•	•	•
62899	Control Box Cover	1	•	•	•
60172-002	Motor/Blower (inch end switch)	1	•	•	•
62901-001	Air Shutter - Stationary Portion	1	•	•	•
61770-002	Air Shutter - Disc	1	•	•	•
62715-003	Air Tube/Housing Assembly	1	•	•	•
63228-001	Pilot Burner	1	•		
63062-001	Pilot Burner	1		•	
62261	Electrode Assembly - DI	1			•
62261-002	Electrode Assembly - DI	1			•
See Chart	Orifices - Natural gas	1	•	•	•
See Chart	Orifices - LP gas	1	•	•	•
60680-002	Pilot Orifice - Natural gas	1		•	
60680	Pilot Orifice - LP gas	1	•	•	
60987	Thermocouple	1	•		
61818	Flamespreader	1	•	•	•
63213-001	Piezo Spark Generator	1	•		
60270-002	Gas Valve - Standing Pilot	1	•		
62246-004	Gas Valve - EP Pilot	1		•	
62374-004	Gas Valve - Direct Spark (DI)	1			•
62243-003	Control - EP Pilot	1		•	
101243-001	Control - Direct Spark (DI)	1			•
63212-001	Spark generator	1	•		
62955-001	Burner Conversion Kit - Nat to LP	1	•	•	
62956-001	Burner Conversion Kit - LP to Nat	1	•	•	
63217-004	Ignitor Wire - Piezo Electrode	1	•		
62947-003	Ignition Wire Assembly	1		•	•
63375-001	Wire Set	1			•