

United States ▼

For Customers

Locate a Sales Office

Product Literature

Search



PRODUCTS AND SYSTEMS

CONTROLS

SERVICES

PARTS & SUPPLIES

MARKETS

ABOUT US

<http://www.trane.com/commercial/north-america/us/en/controls/HVAC-equipment-controls/trane-lontalk-controllers/TechView.html>

> Controls > HVAC Equipment Controls > Chiller Controllers > Tracer CH530 TechView Software Download



Tracer™ CH530 TechView Software Download

Download Support

- ▶ [TechView Installation Procedure](#)
-

TechView is a PC based software tool required for CH530 chiller start-up, commissioning, service, and maintenance tasks. TechView provides the following functions; main processor software download, configuration settings, LLID binding, status and setpoints, diagnostics (active and historic), and mode overrides.

We welcome your perspective and comments to help shape the future of software service tools at Trane. Please fill out this [feedback form](#) to share your thoughts with our software engineers.

United States ▾

For Customers

Locate a Sales Office

Product Literature

Search



PRODUCTS AND SYSTEMS

CONTROLS

SERVICES

PARTS & SUPPLIES

MARKETS

ABOUT US

> Controls > HVAC Equipment Controls > Chiller Controllers > Tracer CH530 TechView Software Download
> TechView Installation Procedure

TechView Installation Procedure

TechView installation has been simplified. All related software, including Main Processor software, is now packaged together with the TechView application resulting in a single installation.

Note: You do not have to uninstall an earlier version of TechView. The new TechView will update the existing files.

To install TechView on your computer

1. Create a new folder titled CH530 (C:\CH530) on your hard drive. This \CH530 folder is the standard location for the installation file. Storing the installation file in this location helps you remember where it is stored and makes it easier for technical support personnel to assist you.
2. Click the **Download** link for the latest version on the TechView Software Download page. The File Download – Security Warning dialog box appears.
3. Click **Save** to copy the installation file to your hard drive. Specify the \CH530 folder you created in Step 1 on the Save dialog box.
4. Double-click the installation (.exe) file. The License Agreement dialog box appears.

5. Click **I Agree** after reviewing the License Agreement. The **Choose Components** dialog box appears. All components are selected by default. (These are the actual MP versions for all units.) Deselect any components you do not want included in the installation.

Note: Deselecting components reduces the size of the installed application.

6. Click **Install**. The Installation dialog appears with a progress meter indicating the percentage of the installation that has occurred. An installation information file appears when the installation is complete.

7. Click **Close** to exit the installation routine.

[Facebook](#) [Twitter](#) [Google+](#) [YouTube](#) [LinkedIn](#) [Newsroom](#) [Careers](#)

[Terms of Use](#) [Contact Us](#)

Explore the Ingersoll Rand family of brands

© Trane 2016. Trane is an equal opportunity and affirmative action employer. [Privacy Policy](#)